

1567 North Bend Dr Tarpon Springs, FL 34689 TEL: 800/356-9080 813/855-6789 www.kloppcoin.com sales@kloppcoin.com

Hi,

Thank you for purchasing the Kisan Newton III Fitness Currency Discriminator. Below are instructions on processing bills for Fitness, and adjusting the levels for Fitness, ATM, and Tape detection.

Fitness Mode

To use the Fitness feature, you first must enter the Fitness Mode, and choose your settings.

- 1. Tap the Mode key until you see 'FITNESS' at the top next to the flag.
- 2. Hold the Mode key for a couple seconds until the screen changes.
- 3. Tap on 'Mix' to highlight it.
- 4. Tap on 'ATM' to highlight ATM processing or 'Fit' for standard Fitness processing. You can have both turned on at the same time, but we recommend only having one turned on at a time.
- 5. On the bottom of the screen, tap 'Tape' to highlight it, and make sure the other 4 items are not highlighted.
- 6. Tap the 'Start/Stop' button to go back to the main screen.
- 7. Run your bills. The ones that are rejected are the Unfit/non-ATM bills, and the ones that go to the bottom pocket are the good bills.

Fitness/ATM Level

The Fitness level is generally used for producing a stack of bills that are in good condition for everyday use in your business. The ATM level is a more strenuous level that produces the best bills possible to use in your ATM's.

- 1. Tap the Menu button.
- 2. Tap 'Fitness Level' on the screen.
- 3. The next screen shows a numbered bar with arrows at each end. Also, there are 2 tabs at the top for 'Fitness' and 'ATM'
- 4. Tap on the tab for which level you want to adjust.
- 5. Use the arrows to raise or lower the level to your desired number. The lower the number, the fewer bills are processed as Fit/ATM. The higher the number, the more bills are processed as Fit/ATM.
- 6. Repeat for the other tab. Each tab is set at its own individual level.
- 7. Once set, tap the 'Ok' button on the screen, then tap the 'Start/Stop' button.

Tape Level

- 1. Tap the Menu button.
- 2. Tap 'Tape' on the screen.
- 3. Use the arrows to raise or lower the level to your desired number. The higher the number, the more sensitive it is to tape. The lower the number, the less sensitive.
- 4. Once set, tap the 'Ok' button on the screen, then tap the 'Start/Stop' button.

If you have any questions, please give us a call and we'll be happy to help.

Thank you,

KLOPP International, Inc.