

KCS Coin Counting Scale: Printer Setup and Usage

1. Plug the 9-pin connector into the side of the Scale. Make sure you have it aligned properly.
2. Plug the USB connector into the side of the Printer.
3. Hold down the Power button to turn the Printer on.
4. Turn the Scale on and wait for the countdown to end.
5. Select the proper Coin Counting Key for coins to be counted. Coin denominations are printed on keys 1 through 6.
6. If you are using a container (bag, bucket, etc.), place the empty container on the Scale, then press the "T" key to zero out the weight of the empty container.
7. Place coins on the platter (or in container) and wait for the arrow to point to "Stable" in the Total Display Window.
8. Press the "M+" key to save the coin count in the scale's memory. This will also print the record. (If finished with all counting, skip to Step #11)
9. Remove coins from platter/container.
10. Select the proper Coin Counting Key for the next coin to be processed. You MUST select the Coin Counting Key, even if you are weighing the same denomination of coin. Repeat steps 7 to 10 as needed, until counting is completed.
11. When finished, press the "Total" key to print Grand Total of all records saved in memory.
12. Press the "Print" key to reprint all the records in memory and the Grand Total.

To review your saved records:

-Press "MR" to enter into record memory and view first saved record. Press "MR" to cycle through the saved records. Once you reach the end of the saved records, the last entry will show your Grand Total of all records.

-Press "CE" to exit memory and return to the coin counting mode.

-Press "MC" to erase all saved information in memory.

Information that is saved in memory is lost when the scale is turn off.