KISAN: K2A 2-POCKET CURRENCY DISCRIMINATOR

BASIC COUNTING MODES FOR PROCESSING MIXED BILLS

WATCH THE VIDEO TO SEE THESE PROCEDURES: **https://youtu.be/Kr4iUlOKcM0**

MIXED BILL COUNTING: (STARTS AT **:38** IN THE VIDEO)

- TAP THE TOUCHSCREEN, AND YOU WILL SEE SEVEN ICONS POP UP. LOOK AT THE BACKGROUND, NEXT TO THE FLAG, TO SEE WHICH MODE YOU ARE IN. TAP **"MODE"** TO SCROLL THROUGH THE AVAILABLE MODES, AND YOU WILL SEE THE MODE CHANGE. SET THE MODE TO **"MIX"**. TAP **"START/STOP"** TO RETURN TO THE MAIN SCREEN.
- YOU SHOULD NOW SEE **"DENOM MIX"** ON THE TOP LEFT UNDER THE FLAG.
- PLACE BILLS INTO HOPPER. COUNTS ALL MIXED BILLS TO BOTTOM STACKER, DISPLAYING QTY AND TOTAL VALUE.
- IF ANY BILLS ARE REJECTED (BAD, SOILED, COUNTERFEIT), YOU CAN CHECK THE REASON BY TAPPING ON THE BLUE **"REJ"** ON THE BOTTOM RIGHT OF THE SCREEN (YOU MUST DO SO BEFORE YOU REMOVE THE BILLS).
  NOTE**: PRIOR TO RUNNING; MAKE SURE **"FACE"** AND/OR **"ORIENT"** SETTINGS ARE TURNED OFF

FACING BILLS: (IN "MIX" MODE): (STARTS AT **1:56** IN THE VIDEO)

- TAP THE TOUCHSCREEN, AND YOU WILL SEE SEVEN ICONS POP UP. HOLD **"MODE"** UNTIL THE SCREEN CHANGES.
- TAP **"FACE"** AND IT WILL TURN LIGHT BLUE. TAP **"START/STOP"** TWICE TO RETURN TO MAIN SCREEN
- YOU SHOULD NOW SEE **"DENOM MIX | FACE'** ON THE TOP LEFT UNDER THE FLAG.
- PLACE BILLS INTO HOPPER. USES BOTH STACKERS (MIDDLE AND BOTTOM) TO PUT BILLS FACED IN ONE DIRECTION IN THE BOTTOM STACKER AND BILLS FACED THE OTHER DIRECTION IN THE MIDDLE STACKER.
- WHEN FINISHED, MATCH THE TWO STACKS, ALL BILLS ARE NOW FACED.
  NOTE**: AFTER RUNNING; MAKE SURE TO UNSELECT **"FACE"** SETTING WHEN FINISHED FACING

ORIENT BILLS: (IN "MIX" MODE): (STARTS AT **2:58** IN THE VIDEO)

- TAP THE TOUCHSCREEN, AND YOU WILL SEE SEVEN ICONS POP UP. HOLD **"MODE"** UNTIL THE SCREEN CHANGES.
- TAP **"ORIENT"** AND IT WILL TURN LIGHT BLUE. TAP **"START/STOP"** TWICE TO RETURN TO MAIN SCREEN.
- YOU SHOULD NOW SEE **"DENOM MIX | ORIENT'** ON THE TOP LEFT UNDER THE FLAG.
- PLACE BILLS INTO HOPPER. USES BOTH STACKERS (MIDDLE AND BOTTOM) TO PUT BILLS FACED IN ONE DIRECTION IN THE BOTTOM STACKER AND BILLS FACED THE OTHER DIRECTION IN THE MIDDLE STACKER.
- WHEN FINISHED, MATCH THE TWO STACKS, ALL BILLS ARE NOW ORIENTED.
  NOTE**: AFTER RUNNING; MAKE SURE TO UNSELECT **"ORIENT"** SETTING WHEN FINISHED ORIENTING

MIXED BILL SORTING: (STARTS AT **3:57** IN THE VIDEO)

- TAP THE TOUCHSCREEN, AND YOU WILL SEE SEVEN ICONS POP UP. LOOK AT THE BACKGROUND, NEXT TO THE FLAG, TO SEE WHICH MODE YOU ARE IN. TAP **"MODE"** TO SCROLL THROUGH THE AVAILABLE MODES, AND YOU WILL SEE THE MODE CHANGE. SET THE MODE TO **"AUTO"**. TAP **"START/STOP"** TO RETURN TO THE MAIN SCREEN.
- YOU SHOULD NOW SEE **"DENOM AUTO"** ON THE TOP LEFT UNDER THE FLAG.
- PLACE BILLS INTO HOPPER. USES BOTH STACKERS (MIDDLE AND BOTTOM) TO SORT THE BILLS.
- SCANS FIRST BILL GOING THROUGH AND COUNTS ALL MATCHING BILLS TO THE BOTTOM STACKER, DISPLAYING QTY AND TOTAL VALUE. ALL OTHER BILLS ARE REJECTED TO MIDDLE STACKER.
- **BATCHING** CAN BE PERFORMED AT THIS TIME FOR STRAPPING BILLS.
  - PRESS THE TOUCHSCREEN TO DISPLAY THE SEVEN ICONS. TAP **"BATCH"** TO SCROLL THROUGH PRESET BATCH AMOUNTS. PRESS THE **"START/STOP"** BUTTON TO RETURN TO THE MAIN SCREEN.
- REPEAT STEPS UNTIL ALL BILLS ARE SORTED AND BATCHED FOR STRAPPING
  NOTE**: PRIOR TO RUNNING; MAKE SURE **"FACE"** AND/OR **"ORIENT"** SETTINGS ARE TURNED OFF